

Step 1. Drawer box and clips



Step 2. Clips and boxes notched on back



Step 3. Cabinet HW installed and extended



Step 4. Cabinet HW installed to back sockets



Step 5. DB laying on extended HW prior to being engaged



Step 6. Engaging right hand HW into DB



Step 7. View from back of engaged left HW with tang in DB predrilled hole



Step 8. View from back of engaged right HW tang in DB predrilled hole.



Step 9. Installed DB fully extended.



Step 10. Installed DB fully closed.

